

unichrome

TRITON

THAMES

Single hole bath filler



Installation Instructions

INSTALLERS PLEASE NOTE THESE INSTRUCTIONS ARE TO BE LEFT WITH THE USER

2180434B October 2005

INTRODUCTION

This guide contains all the necessary fitting instructions for your Unichrome single hole bath filler.

Note: This tap is suitable for use with single hole style baths only.

Please read this guide carefully before beginning your installation.

The bath filler installation must be carried out by a suitably competent person and in the sequence of the instruction book.

Care taken during the installation will provide a long life and trouble free operation from your tap.

DO NOT **INSTALL** **THE TAP**
IF YOU **ARE** **UNSURE**

Replacement parts should be ordered from Triton Customer Service (see page 10).

WARNING

This tap is not suitable for high pressure water systems. It is not to be used in applications with water pressure in excess of 10 bar.

COLOUR

The tap is available in the following colours:

Check

Check

Check

Check

Check

Check

Check

Check

Check

Check

Check

Check

Check

Check


Check

Check

Check

Check

WARNING!
The tap must not be positioned where it will be subject to freezing conditions.



INSTALLATION

DO NOT use jointing compounds on any pipe fittings for the installation.

Fitting the tap

Screw the stud into the hole in the base of the tap unit and secure. Fit the steel braided hoses into the hot and cold inlets (**fig.2**) and tighten to secure.

Slide the silicon 'O' ring seal over the hoses and into the recess in the base of the tap. Feed the braided hoses through the opening in the bath and place the tap assembly in place. Make sure the 'O' ring sits correctly in the base of the tap when on the bath.

Slide the silicon horseshoe seal and horseshoe plate over the stud and secure the tap assembly in place using the nut provided (**fig.3**).

DO NOT overtighten the nut as this may damage the tap unit and bath.

FINISHING THE INSTALLATION

IMPORTANT: Before completing the connection of the water supply to the inlets of the tap, flush out the system to remove any debris in the pipework. To do this, connect a hose to the pipework and turn on the mains water supply long enough to clear the debris to waste.



Connect the steel braided hoses to the hot and cold supplies using standard 1/2" BSP tap connectors.

OPERATION

The tap has a lever for both flow control and temperature control. Lift the lever to start the flow of water (**fig.4**) and push the lever down to stop the water flow. Turn the lever left for hotter and right for cooler water.

CLEANING

IMPORTANT: DO NOT use abrasive or solvent cleaning fluids. The tap unit should be cleaned using a soft cloth and warm water. Any stains should be removed using washing up liquid.



SPARE PARTS

Description	Part No.
45mm ceramic cartridge	83308510
Handwheel	83308500
Complete anti-splash tap	83308090

TRITON STANDARD GUARANTEE

Triton Plc guarantee this product against all mechanical defects arising from faulty workmanship or materials for a period of five years for domestic use only, from the date of purchase, provided that it has been installed by a competent person in full accordance with the installation and operating instructions.

Any part found to be defective during this guarantee period we undertake to repair or replace at our option without charge so long as it has been properly maintained and operated in accordance with the operating instructions, and has not been subject to misuse or damage.

This product must not be taken apart, modified or repaired except by a person authorised by Triton Plc. This guarantee applies only to products installed within the United Kingdom and does not apply to products used commercially.

This guarantee does not affect your statutory rights.

What is not covered:

- 1** Breakdown due to: *a)* use other than domestic use by you or your resident family; *b)* wilful act or neglect; *c)* any malfunction resulting from the incorrect use or quality of gas or water or incorrect setting of controls; *d)* faulty installation.
- 2** Repair costs for damage caused by foreign objects or substances.
- 3** Total loss of the product due to non-availability of parts.
- 4** Compensation for loss of use of the product or consequential loss of any kind.
- 5** Call out charges where no fault has been found with the unit.
- 6** The cost of routine maintenance, adjustments, overhaul modifications or loss or damage arising therefrom, including the cost of repairing damage, breakdown, malfunction caused by corrosion, furring, pipe scaling, limescale, system debris or frost.

Replacement Parts Policy

Availability: It is the policy of Triton to maintain availability of parts for the current range of products for supply after the guarantee has expired. Stocks of spare parts will be maintained for the duration of the product's manufacture and for a period of five years thereafter.

In the event of a spare part not being available a substitute part will be supplied.

Payment: The following payment methods can be used to obtain spare parts:

- 1** By post, pre-payment of pro forma invoice by cheque or money order.
- 2** By telephone, quoting credit card (MasterCard or Visa) details.
- 3** By website order:

www.tritonshowers.co.uk

Triton Plc, Triton Road,
Nuneaton, Warwickshire. CV11 4NR

To use your Triton Guarantee please contact Triton Customer Service

on +44 (0) 87 0067 8678 (Scotland +44 (0) 84 5762 6591). Please have your postcode and model details available when you call.

Please note: Telephone calls may be recorded for training purposes.

Customer Service

☎ **+44 (0) 87 0067 8678**

Scottish and Northern Ireland

Customer Service

☎ **+44 (0) 84 5762 6591**

Trade Installer Hotline

☎ **+44 (0) 24 7632 5491**

Fax: +44 (0) 24 7632 4564

www.tritonshowers.co.uk

E mail: technical@triton.plc.uk